



OrCam Read Lightstand

OrCam Read Audiostand - Manual.

Copyright © 2023 - Sensotec NV

All rights reserved.

Other product and company names mentioned herein may be trademarks or registered trademarks of their respective owners.

Version: 1.0.

Producer contact details :

Sensotec SA - Vlamingveld 8 - BE-8490 Jabbeke.

info@sensotec.be - www.sensotec.be.

Head office :

Vlamingveld 8, B 8490 Jabbeke

T +32 50 39 49 49 - F +32 50 39 49 46

sales@sensotec.be

Introducing the OrCam Read Lightstand

Thank you for choosing the OrCam Read as your solution to make you read the text aloud. Thanks to the special stand developed by Sensotec, blind users can also use this device as a reading device. The tripod is partly made of aluminium, measures 29 cm when unfolded and weighs only 475 g. Light and compact, you can therefore easily carry it in your bag. The ideal tool for working, reading, etc. at home and on the go, ensuring more independence in your daily life.

Package contents

The kit you received contains the following items:

- The OrCam read holder
- A tripod
- A screw

Always check beforehand that all components are there!

Care and maintenance

Clean your OrCam Read Lightstand with a damp, well-wrung cloth (NEVER use a wet blanket). Never use corrosive products: this will cause irreparable damage to the product.

Keep the packaging in which the OrCam Read Lightstand was delivered. The device can only be shipped in this packaging.

Warranty

Sensotec NV offers a warranty on the OrCam Read Lightstand for a maximum of two years after purchase, in accordance with the statutory warranty provisions.

Damage caused by inappropriate or negligent use is not covered by the warranty.

Maintenance and repair work may only be carried out by Sensotec nv technicians. The device must never be opened by the user or third parties. Should this happen, your warranty will expire without any obligation on our part.

Technical support.

Finally, you can contact your local supplier for technical assistance. If the technical problem persists, or if you cannot find the answer to your question in this manual, please do not hesitate to contact us by e-mail (support@sensotec.be) or by telephone on +32 50 40 47 47.

The OrCam Read Audiostand components

Overview

- The OrCam read holder (a)
- A tripod (b)
- A screw (c)



How to assemble the various components

- 1) Take the tripod (b) and assemble it with the the OrCam Read holder (a). You will notice that there is a raised dot (x) in the middle of the tripod and under the the OrCam read holder in the middle (x). This holds the two elements together.



- 2) Take the screw (c) and screw the two elements together.



- 3) Your device is ready





Solutions for a visual challenge

Do you have technical or practical questions about this product? You can't find the answer in this manual? Then our Service & Support colleagues are here to help you!

Service & Support

+32 50 40 47 47 | support@sensotec.be

Contact

sales@sensotec.com | www.pro.sensotec.com

Sensotec HQ
Vlamingveld 8
B-8490 Jabbeke
+32 50 39 49 49

Sensotec The Netherlands
Kalfjeslaan 38,
NL-2623 AJ Delft
+31 15 262 59 55